

Caribou SOLAS Tape Kit Installation

Suggested Installation: Clean the cases thoroughly with soap and water, let dry completely. Cut the tape into 4 equal 1 foot lengths. Wrap the tape along the rounded outer edges of the lid of the cases. This provides reflectivity forward, rearward, and side. On the 40L case you will have to cut sections to fit in between the fins. For a top case, use the remaining 2 sections on the back of the case (facing rearward from the bike).

